



TECHSPEC

SPECIFICATION DATA

Service: Steam, air, gas (including oxygen)

Sizes: 1/2", 3/4", 1", 1-1/4", 1-1/2", 2", 2-1/2", 3", 4", 5" and 6"

Connections:

Threaded - 1/2" through 2"

CL 125 - 2-11/2" through 6"

CL 150 & 300 - 1/2" through 6"

Body: Bronze, cast iron, cast steel and stainless steel.

Maximum Temperature: To 750°F
(See page 5)

Maximum Initial Pressure: To 740 psig
(See page 5)

Outlet Pressure Range: 1-300 psig
(See page 5)


Capacity: Refer to bulletin PRV-G4 for capacity information.



Type G4

PILOT OPERATED PRESSURE REDUCING REGULATOR

INSTALLATION - GENERAL



Sizing The correct sizing and layout of regulators, pipework, stop valves, strainers, and other fittings is extremely important for good performance. See PRV-G4 and sizing program.

Inlet Strainer Dirt, grit, and pipe scale are common causes of regulator failure. A strainer of upstream pipe size should be installed at least 10 pipe diameters before the regulator.

Relief Valve Every installation should be protected against regulator failure by a Relief or Excess Pressure Protection Valve. Care should be taken that the discharge from such a valve cannot cause damage to property or create a hazard to persons.

Pipe Strain All pipe work and fittings should be properly supported and free from any strain which could affect their correct operation. All flanges should be correctly aligned and gaskets carefully fitted to avoid blockage of valve ports. If a jointing compound is used it should

not be allowed to foul internal ports or working parts of the valve.

Remote Sensing Connection The G4 pressure regulator is a pilot-operated, self-actuating, pressure reducing valve and relies upon a stable pressure signal from the outlet piping in order to maintain stable control of the outlet pressure.

However, under certain operating conditions the signal pressure may be unstable in the immediate vicinity of the valve outlet and as a result may cause erratic control.

This can be easily overcome by installing a remote sensing connection. All G4 regulators can be remotely controlled, where necessary, by connecting a remote sensing connection from the remote control port and into the outlet piping at a point where stable pressure conditions are likely to occur. Ideally it should be installed into a straight length, correctly sized section of the outlet piping. The remote sensing

connection should, normally be not less than 6 feet long, and must be screwed into the remote control port to a depth not less than one inch. It should also include a pipe union and stop valve to enable dismantling and isolation. Wherever possible, the remote sensing connection should be installed with a steady fall away from the regulator into the outlet piping to facilitate self draining of condensate.

We recommend that a remote sensing connection be installed when the following conditions apply:

1. When the reduced pressure is below 55% of the inlet pressure.
2. When a low pressure top assembly is installed.
3. Whenever difficult outlet piping conditions occur.

(Refer to Figure 2 on page 2)

This Bulletin No.	
Date Of This Issue	JULY 2000
Supersedes Bulletin No.	
Dated	JAW 1999

INSTALLATION, MAINTENANCE, & REPAIR PARTS INFORMATION

ISO 9001 Certified




Figure 2

FIRST AID

Regulators occasionally give trouble (particularly on new installations) due to dirt and other foreign matter fouling the internals. In this event the trouble can often be quickly eliminated by applying the following first aid treatment:

1. With pressure 'off', remove complete valve top assembly (which is secured by four nuts) and check by 'pushing down' that the piston and main valve are moving freely and that the main valve returns quickly to its

seat. Unscrew bottom plug and withdraw main valve. Clean all parts and re-seat main valve if necessary. Re-assemble and test.

IF IT IS STILL NOT WORKING PROPERLY - TRY 2

2. Remove top cap, adjusting screw, spring top cover and diaphragm. Check spring, diaphragm and gasket. Turn on service supply and close outlet stop valve.

IF IT IS STILL NOT WORKING PROPERLY - TRY 3

3. With pressure off, unscrew pilot valve plug, check pilot valve, spring, and seat. Clean and re-seat if necessary. Check the pilot valve plug bottom gasket (copper). Reassemble and test.

INSTALLATION-SETTING

Before putting a regulator in to service

All pipes should be thoroughly blown-down to remove any dirt, grit or pipe scale. This can be done by removing the regulator bottom plug, main valve and spring, and carefully opening the inlet stop valve by a small amount. Remove any dirt lodged in the valve body and replace the parts.

Setting Under No-Flow Conditions

This is the more accurate method and may be carried out as follows:

1. Condensate should be removed from the pipeline by first applying a little tension to the regulator adjusting spring (by rotating the adjusting screw clockwise for a few turns) and then slowly opening the outlet and inlet stop valves. When the downstream pressure starts to rise, close the inlet stop

valve and remove all tension from the regulator adjusting spring.

2. Close the outlet stop valve and slowly open the inlet stop valve. Wait for about one minute to confirm that the reduced pressure is maintained at zero. This is a check that the regulator gives 'absolute-tight' shut-off under no-flow conditions.

3. Slowly raise the reduced pressure (by rotating the regulator adjusting screw clockwise) until the desired pressure is obtained. (Do not forget to set the relief valve, if necessary.) The valve is now correctly set and the adjusting screw should be locked with the lock-nut provided.

4. Slowly bring the outlet stop valve to fully 'open'. The regulator should continue to maintain the reduced pressure just below the 'set' value.

Special Note

The regulator should be kept under supervision for the first few days after its installation and any defects which may occur as the new system settles down should be noted.

It is strongly recommended that the inlet strainer and reducing valve should be cleaned out one week after installation, and the strainer cleaned out at regular intervals thereafter.

Outlet Pressure Regulation

Up to 3" size $\pm 1/2\%$ ($\pm 1/2$ psig below 100 psig)

Above 3" size $\pm 1\%$ (± 1 psig below 100 psig)

Pressure rise to dead end = 1%

SERVICING

G4 Regulators should be given a complete service every 12 months. They should, if possible be removed from the line, stripped down and each part examined and put aside in order of removal to simplify re-assembly.

For a complete service carry out Instructions contained in sections (1) to (5) Inclusive.

1. Changing Adjusting Springs

Unlock the valve, remove the top cap, and completely unscrew the adjusting screw. Replace spring using existing top and bottom spring plates and re-assemble.

2. Changing Diaphragms

Remove adjusting spring. Standard Top: Remove the pilot valve body top cover by undoing four cap-headed screws. Remove the diaphragm and gasket. (Two diaphragms should be fitted if the reduced pressure is 150 psig or above.) Low pressure top: This has a larger diaphragm than standard which is removed by undoing twelve bolts and nuts, and detaching the top cover. The top cover has a beaded gasket instead of the separate diaphragm gasket and care should be taken not to damage it. The low pressure top is necessary for reduced pressures of 5 psig or less.

DIAPHRAGM CONDITION

All flat diaphragms become "molded" by the

reduced pressure without detriment to their performance. They should only be replaced if sharp concentric or radial ridges or fractures develop. It should be possible to flex the central area of the diaphragm using both hands, and produce an 'oil-can' effect, even if it is molded. Diaphragms which are too rigid should be rejected.

PILOT VALVE STANDOUT

Check that the pilot valve cap is in line with the top surface of the diaphragm gasket (or the push-rod and the top face of the adapter flange in the case of the low pressure top). This can be done by resting a saw-blade across the gasket and through the slot provided in the flange. This height should be adjusted by filing down the pilot valve cap (or push-rod). Re-assembly is otherwise relatively simple.

3. Pilot Valve

Remove adjusting spring and diaphragm (see sections 1 and 2) and the adapter flange and push-rod if a low pressure top. Remove pilot valve cap and unscrew pilot valve plug (with removing key or box wrench) and withdraw pilot valve and spring. Check copper plug gasket.

The pilot valve has a soft seat valve and stainless steel or bronze spindle. The valve should be replaced if worn. When re-assem-

bling pilot valves, check the standout as described in section (2). The torque required to obtain a good seal between the pilot valve and copper washer is approximately 120 lbs.ft.

4. Piston and Rings

Remove the top assembly completely from the main valve. Withdraw the piston and rings and mine them, the liner and guide. For wear and deposits. Refer to factory for piston ring gap specifications.

Clean and re-assemble. The piston should move quite freely with only a light pressure required to overcome frictional resistance. Take care, that when the main flange body top gasket is replaced, it does not cover the relay ports.

5. Main Valve

Remove the bottom plug or cover and withdraw the main valve spring. Examine both the valve and seat for deposits or erosion (evidence of the latter would indicate that the regulator is oversized or subjected to long periods of operation at very low loads). Replace if visible damage is present. Re-assemble the main valve, spring and bottom plug or cover.

RECOMMENDED SPARE PARTS

A. Routine Service Packages

Each contains: 1 Diaphragm
1 Set of Piston Rings
1 Pilot Valve Cap
1 Set of Gaskets

These parts enable a valve to be stripped down and re-assembled as part of a routine maintenance check. It is assumed that the valve is in good working order and that other parts would not be required.

B. Complete Repair Kits

Each contains - 1 Diaphragm
1 Set of Piston Rings
1 Pilot Valve Assembly
1 Main Valve
1 Main Valve Seat
1 Main Valve Spring
1 Set of Gaskets

These are for use when a valve is known to be giving trouble and a complete set of parts may be needed to put it into good working condition.

Each carton of parts contains a leaflet which identifies the particular parts and illustrates the most common causes of reducing valve problems. These are in the form of a series of 'Check Points,' which should be referred to in the course of an overhaul.

DIAPHRAGMS (Sis of valve up to 4')

REDUCED PRESSURE RANGE	DIAPHRAGM DIA.	CODE NO.	NO. REQUIRED	NOTES
5 psig and below	5"	011855	One	Low Pressure Top
5 - 150 psig	3-1/4"	011844	One	Standard Top
150 psig and above	3-1/4"	011844	Two	Standard Top

SPRING IDENTIFICATION (Sizes of valve up to 4")

SPRING RANGE	CODE NO.	COLOR CODE*	WIRE DIA.	NOTES
1 - 5 psig	C0330	Yellow	5/32"	Use Low Pressure top
5 - 50 psig	C0330	Yellow	5/32"	
10 - 100 psig	C0331	Black	3/16"	Standard Top
40 - 150 psig	C0332	White	7/32"	(2 Diaphragms required for reduced pressures of 150 psig and above.)
50 - 200 psig	C0333	Green	1/4"	
100 - 300 psig	C0334	Red	9/32"	

TROUBLE SHOOTING


SYMPTOM	POSSIBLE CAUSE	REMEDY
A. Leakage from spring chamber Mead hole.	Broken diaphragm	Replace diaphragm and gasket
B. Reduced pressure not maintained as flow varies. Relief valve blows when flow ceases.	Piston stuck due to:	
	(a) Dirt in chamber	Clean out and re-assemble. Check inlet strainer and clean if necessary.
	(b) Excessive deposit of solids from fluid.	Clean out and re-assemble. Check condensate and modify water treatment as necessary.
	(c) Broken or scored piston rings.	Replace and check piston ring gap.
	(d) Scored piston liner	Replace and check piston ring gap.
	Main valve stuck in guides.	Free and if necessary replace worn parts.
C. Reduced pressure not maintained when flow approaches maximum, but is correct at "low-flow" and "no-flow" conditions,	Relay port between diaphragm chamber and valve outlet blocked.	Clear blockage
	Regulator undersized	Replace with larger valve or consider installing another regulator in parallel. (assuming piping is suitable for larger capacities)
	Pressure differential across the regulator too small.	None - unless inlet or reduced pressure can be adjusted to give increased differential.
	Downstream piping and fittings undersized.	Try installing a remote sensing connection, or increasing size of piping.
D. Reduced pressure builds up on "no-flow" conditions but otherwise operates correctly.	Upstream pressure not being maintained.	None - this is a basic system fault that needs to be corrected.
	Main valve damaged or stuck in guides.	Replace main valve. Check that regulator is not oversized.
	Pilot valve damaged	Replace pilot valve.
E. Violent reduced pressure fluctuations under all flow conditions.	Inlet fluid leaking past pilot valve plug gasket.	Tighten down pilot valve plug. Renew copper gasket if necessary.
	Inlet pipe gasket and/or strainer and fittings undersized.	If badly undersized, replace pipework and fittings.
	Relay port from valve inlet to pilot valve partially blocked	Clear blockage
	Regulator oversized	Fit small regulator or replace main valve with restricted main valve.
	Inlet flange gasket restricting flow to regulator	Rectify gasket

SYMPTOM	POSSIBLE CAUSE	REMEDY
F. Reduced pressure erratic under all conditions.	Main Valve spring weak or broken	Replace
G. Reduced pressure oscillates slowly	Relay port diaphragm chamber to valve outlet partially blocked	Clear blockage
H. Reduced pressure not obtainable (regulator will not open when adjusted)	Relay port from between valve inlet and pilot valve blocked.	Clear blockage
	Main valve or piston stuck in closed position.	Check and service as necessary.
I. Fluid leaking through gaskets.	Gaskets not properly tightened	Adjust as necessary
J. Gaskets de-composing	Maximum recommended working temperature of the valve exceeded	Replace with appropriate type of regulator.
K. Appreciable reduced pressure rise on "no-flow" but correct at flow conditions.	Pilot valve stand out too high	Adjust. See inspection and servicing instructions.
L. Appreciable fall of reduced pressure to open valve from "no-flow" condition.	Pilot valve stand out too low	Adjust. See inspection and servicing instructions.

SPECIFICATIONS

	Fig 2042						Fig 2043						Fig 2044						Fig 2046					
Size	1/2	3/4	1	1 1/4	1 1/2	2	1/2	3/4	1	1 1/4	1 1/2	2	2 1/2	3	4	5	6	1	2	2 1/2	3	4	5	6
A	4 1/4	4 1/4	4 1/4	4 1/4	5 1/4	6 1/4	5 1/4	5 1/4	6 1/4	7	7 1/4	8 1/4	10	11 1/4	13 1/4	16	16 1/4	6 1/4	9	10	11 1/4	13 1/4	16	16 1/4
B	8	8 1/4	8 1/4	9 1/4	9 1/4	10 1/4	8	8 1/4	8 1/4	9 1/4	9 1/4	10 1/4	11 1/4	12	13 1/4	16 1/4	17 1/4	8 1/4	10 1/4	11 1/4	11 1/4	12 1/4	15 1/4	16 1/4
C	2 1/4	2 1/4	2 1/4	3	3 1/4	3 1/4	2 1/4	2 1/4	2 1/4	3	3 1/4	3 1/4	5 1/4	5 1/4	6 1/4	9	9 1/4	2 1/4	3 1/4	5 1/4	5 1/4	7	8 1/4	9 1/4
WLb.	13.2	15.0	15.4	23.8	28.0	33.9	17.6	18.9	19.8	30.0	35.9	45.8	77.0	104.0	174.0	247.0	351.0	30.0	58.0	93.0	115.0	192.0	273.0	381.0

DIMENSIONS



PRESSURE TEMPERATURE RATINGS

Material		End Connection	Pressure (psig)						
Description	ASTM Spec.	ANSI Class	0 to 150F	250F	300F	400F	450F	500F	750F
Cast Iron	A126 Class B	CL125 (Iron)	200	175	160	135	125	-	-
		CL150 (Bronze)	225	185	180	150	-	-	
		CL300 (Bronze)	500	425	390	300	-	-	
Carbon & Stainless Steel	A216 GR WCB / A361 CF8 (304)	CL150 (Steel)	285	245	230	195	185	170	-
		CL300 (Steel)	740	660	655	630	615	590	500
		CL250 (Steel Threaded)	600	530	525	500	490	470	460

* 570F for 150 psig

SPRINGS

VALVE SIZE		
1/2" - 4"		5" & 6" *
5 - 50	(Yellow)	5 - 20
10 - 100	(Black)	10 - 50
40 - 150	(White)	40 - 100
50 - 200	(Green)	50 - 175
100 - 300	(Red)	



*Not Color Coded

PARTS INFORMATION

- 1 Body
- 2 Main Valve
- 3 Main Valve Seat
- 4 Bottom Plug
- 5 Piston
- 6 Piston Rings
- 7 Piston Liner
- 8 Piston Guide
- 17 Valve Body Top Gasket
- 21 Main Valve Spring
- 24 Bottom Plug Gasket
- 25 Pilot Valve fop
- 26 Pilot Valve-
 - A. Stem
 - B. Valve
 - C. Guide
- 27 Pilot Valve Plug
- 28 Pilot Valve Cap
- 29 Diaphragm
- 30 HP Port Plug
- 31 Pilot Valve Spring
- 32 Pilot Valve Top Cover
- 33 Adjusting Spring
- 34 Adjusting Spring Bottom Plate
- 35 Adjusting Spring Top Plate
- 36 Adjusting Screw
- 37 Locking Ring
- 38 Padlock
- 42 Diaphragm Gasket
- 43 HP Port Plug Gasket
- 44 Cap Headed Screws
- 61 Top Cap
- 68 Pilot Valve Plug Gasket (Copper)
- 69 Remote Control Plug
- 70 Remote Control Plug Gasket
- 97 Adjusting Screw Ball

Low Pressure Top Only

- 49 Diaphragm
- 50 Screw Gaskets
- 51 Adapter Flange
- 52 Top Cover
- 53 Push Rod
- 54 Top Cover Bolts
- Keep Plate) Fig. 2046
- Keep Plate Screw) Valves Only



The illustration shows Fig. 2W2
Other types have essentially
the same parts.

HOW TO ORDER

To order repair parts, refer to the cutaway view of the Type G4 to identify the part required. When ordering, please use the names listed and provide the valve assembly number. Also provide the following G4 Information:

1. Valve size
2. Service (Air, steam, etc.)
3. Inlet pressure
4. Outlet pressure range and setting
5. Part description
6. Quantity of each part
7. Valve assembly or serial number



IMI CASH VALVE INC,
2400 7TH AVENUE SW • CULLMAN, ALABAMA 35055
1-800-879-2042 • FAX 1-800-879-2057
256-775-8200 • FAX 256-775-8238
www.cashacme.com

© 2000 IMI CASH VALVE INC.